



| Main menu | Sub menu | Adjustments | Factory setting | Own setting | Setting range |
|---------------|----------|---------------|-----------------|-------------|--|
| Start options | | Starting time | 22:30 | | 00:00 till 23:59 / Step: 1 min |
| Day phases | Daybreak | Starting time | 5:00 | | |
| | | Time factor | F: 300 | F: | F: 1, 3, 6, 20, 40, 60, 100, 200, 300, 400, 500, 600 |
| | Day | Starting time | 12:00 | | |
| | | Time factor | F: 300 | F: | F: 1, 3, 6, 20, 40, 60, 100, 200, 300, 400, 500, 600 |
| | Dusk | Starting time | 17:00 | | |
| | | Time factor | F: 300 | F: | F: 1, 3, 6, 20, 40, 60, 100, 200, 300, 400, 500, 600 |
| | Night | Starting time | 23:00 | | |
| | | Time factor | F: 600 | F: | F: 1, 3, 6, 20, 40, 60, 100, 200, 300, 400, 500, 600 |